


# HAND BEVELER HB-15B ASSEMBLY AND PARTS LIST



The part numbers with ( ) are included in the Ass'y parts written above them.

No.	Part No.	Part Name	Q'ty	Price
2	TP04157	Nut for Roller Bearing AN03	2	
3	TA9A066	Tip Holder A Ass'y	1 set	
4	TA9A067	Tip Holder B Ass'y	1 set	
5	(TP04689)	Hex. Socket Head Set Screw 6 x 8	12	
6	TP16594	Tip 12.7 sq.	12	
7	TP16152	Adapter	1	
8	TQ00208	Hex. Socket Head Screw 6 x 12	8	
9	TQ00207	Plate C	1	
10	TP16124	Plate Guide	2	
11	TQ00205	Plate A	1	
12	TP06217	Hex. Socket Head Bolt 6 x 25	4	
13	TP00092	Plain Washer M6	4	
16	TA9A074	T-Handle Ass'y	1 set	
17	TP16159	Clamp Lever	1	
18	TP08584	Hex. Nut M8	1	
19	TP10978	Plain Washer M8	2	
20	TP07353	Hex. Socket Head Bolt 8 x 30	1	
21	TA99911	Body Sub Ass'y	1 set	
22	TA92089	Sub Handle Ass'y	1 set	
25	TP16151	Sunk Key 5 x 5 x 36	1	
29	TA9A757	Cabtyre Cable Ass'y	1 set	

## ACCESSORIES

No.	Part No.	Part Name	Q'ty	Price
30	TQ03353	Hex. Socket Head Cap Screw 10 x 30 with Spring Washer	1	
31	TB02203	Motor Ass'y (200-240V)	1 set	
32	TB02204	Motor Ass'y (110-120V)	1 set	
	TP16613	T Wrench Key 3	1	
	TP01939	Hex. Wrench Key 4	1	
	TP04004	Hex. Wrench Key 5	1	
	TP00170	Hex. Wrench Key 6	1	
	TP04309	Spanner 24 x 27	1	
	TP16410	Hook Spanner 25-28	1	
	TQ00206	Plate B	1	
	TA99834	Roller Bracket Ass'y	1 set	
	TP16600	Spacer A	1	
	TP16601	Spacer B	1	
	TA9A093	Tip 12.7 sq. (12 pcs. each/sheet)	1 set	
	TQ02984	Instruction Manual	1	

## OPTIONAL ACCESSORIES

	TA9A093	Tip 12.7 sq. (12 pcs. each/sheet)	1 set	
	TA9A728	Plate Ass'y for Pipe	1 set	