


CIRCUIT BEVELER CB-02 ASSEMBLY AND PARTS LIST



The part numbers with () are included in the Ass'y parts written above them.

No.	Part No.	Part Name	Q'ty	Price
1	TP00112	Cross recessed countersunk Head Screw 4 x 10	4	
2	TB00668	Disk sub Ass'y	1set	
40	(TP17131)	Drive Screw 2 x 3.2	4	
41	(TQ00851)	Warning Plate	1	
3	TQ00629	Adjuster	1	
4	TQ00632	Lock Ring	1	
5	TP00511	Cross recessed Pan Head Screw 5 x 15	4	
6	TP00513	Spring Washer M5	4	
7	TQ00631	Housing Connector	1	
8	TQ00633	Packing	1	
9	TQ00627	Hex. Cap Nut M4	1	
10	TP04234	Spring Washer M4	1	
11	TQ00625	Ball Bearing L1150ZZ	1	
12	TQ00626	Tip Setting Screw	1	
13	TP16967	Tip 9.525 sq.	1	
14	TQ00624	Cutter spindle	1	
15	TP01913	Ball Bearing 6000ZZ	1	
16	TP01911	End Plate B	1	
17	TP01912	Distance collar	1	
18	TA9A212	Blade Ass'y (4 pcs.)	1 set	
19	TQ00623	Rotor	1	
20	TP10000	Cylinder	1	
21	TP01907	End Plate A	1	
22	TP00468	Ball Bearing 608ZZ	1	
23	TB01269	Housing Ass'y	1 set	
42	(TQ00658)	Drive Screw 1.85 x 3.2	4	

No.	Part No.	Part Name	Q'ty	Price
43	(TQ02321)	Name Plate CB-02 Exp.	1	
44	(TQ02207)	Warning Label CE Mark	1	
24	TP16050	Packing A	1	
25	TP16047	Valve Body	1	
27	TP02638	Cross recessed Pan Head Screw 4 x 12	4	
28	TB01152	Throttle Lever Ass'y	1 set	
29	(TP05498)	Spring Pin 2 x 16	1	
30	(TP00460)	Spring Pin 3 x 22	1	
32	TA93070	Valve Stem Ass'y	1 set	
33	TP06325	Adjust Valve	1	
34	TP11997	O-Ring KS-7	1	
35	TP06326	Spacer 6 x 12 x 1.2	1	
36	TP03695	Retaining Ring C-12	1	
37	TP09153	Stop ring 0-27 x 2.6	1	
38	TA96867	Air Hose Sub Ass'y A 1/4	1 set	
39	TQ01664	Exhaust Hose	1	

ACCESSORIES

	TP02236	Bushing PT1/4 x NPT1/4	1	
	TA9A639	Tip 9.525 sq.	1	
	TP16980	Spanner T-9F	1	
	TQ00636	Hook Spanner 58-62	1	
	TQ00637	Protective cap	1	
	TQ00638	Gauge	1	
	TQ00852	Instruction Manual	1	